



PROTECTIVE CLOTHING AND FACE MASK LEAKAGE TESTER

Protective Clothing and Face Mask Leakage Tester ToronFMPC™ LT is evaluated for its ability to shield against solid airborne particles, including radioactive contaminants. The testing process measures "inward leakage (%)" by calculating the ratio of contaminant concentration in the surrounding atmosphere to the concentration inside the suit.

APPLICATIONS

Standards

1. ISO 13982
2. BS EN ISO 13982
3. EN149
4. EN 1073-1-2016

Control and Analysis System

The testing process is managed by a central control console with computer-programmed automation. Key features include:

1. Automated monitoring of test data.
2. Calculation of individual and overall inward leakage rates.
3. Automatic computation of average inward leakage values.
4. Generation of test results in multiple formats.

FEATURES


A standard aerosol of sodium chloride particles is introduced into a test chamber. Inside the chamber, a participant wearing the protective suit performs a series of predetermined exercises. Flame photometry is used to measure inward leakage at various sampling points inside the suit. The following indicators are used to assess the performance of the protective clothing:

- **Lijmn**: Inward leakage for a specific test subject (i), suit (j), exercise (m), and sampling position (n).
- **Cijmn**: Aerosol concentration measured at the sampling position inside the suit for a specific test subject (i), suit (j), exercise (m), and sampling position (n).
- **Ls**: Total inward leakage per suit (average across all exercises and sampling positions).
- **LH**: Total inward leakage per participant (average across all exercises, sampling positions, and suits worn by that participant).
- **LE**: Total inward leakage per exercise (average across all suits and sampling positions).
- **Lp**: Total inward leakage per sampling position (average across all suits and exercises).
- **LEP**: Total inward leakage per sampling position and exercise (average across all suits).
- **L**: Mean total inward leakage (average across all participants, suits, exercises, and sampling positions).

TECHNICAL SPECIFICATIONS

Model	ToronFMPC™ LT	
Environmental Requirement	Working Temperature	(20±5)°C
	Humidity	≤60%
	Used Space	≥4000×5000×3000mm, water in/drain pipe, room with good ventilation
Walked-in Testing Room	Inner Effective Size	1800mm×1500mm×2100mm (L×W×H)

Model	ToronFMPC™ LT	
Outer Size of Testing Room	1950mm×1650mm×2500mm (L×W×H)	
Control Cabinet	700mm×700mm×1600mm (L×W×H)	
Environmental Analog Detection System	Particle Aerosol Concentration	(10±1) mg/m ³
	Aerodynamic Size Distribution of Particle	(0.02~2) μm
	Mass Median Diameter	About 0.6 μm
	Concentration Variation in Effective Space	≤10%
	Occurrence Amount	≥100L/min
Particle Concentration Detector	2 Sets	
	Dynamic Range	(0.001~200) mg/m ³
	Accuracy	±1%
	Response Time	≤500 ms
Horizontal Pedal Drive Test-bed	Running Speed	(5±0.5) km/h
Other Accessories	Air duct circulation and maintenance of cleaning equipment	



Torontech Inc.

251 Consumers Road, Suite 1200
Toronto, Ontario, M2J 4R3, Canada 

Phone: +1 416 368 2721 | Fax: +1 416 981 7652
Email: info@torontech.com

Torontech, LLC

601 Brickell Key Drive, Suite 700
Miami, FL 33131, USA 

Toll-Free: 1-866-383-7919
Email: sales@torontech.com

Torontech ME FZE

Meydan Grandstand, 6th Floor,
Meydan Road, Nad Al Sheba,
Dubai-261440, UAE 

Phone: +971 488 19252
Email: me@torontech.com

