



ALLOY ANALYZER

The TrueX Handheld Alloy Analyzer, powered by the latest scientific advancements, including the Handheld XRF Analyzer, is a robust instrument for identifying metal materials during production. With its rapid, precise, and handheld features, it enables on-site detection and swift sorting of large volumes of metal waste, furnishing users with prompt, effective, and precise data.

Handheld XRF Analyzer - Alloy Analyzer proves invaluable in various industries such as quality control (QA/QC), material analysis (PMI), mixture identification, waste sorting (Recycling), Grade ID in steel smelting, non-ferrous metals, petrochemical refining, fine chemical industry, pharmaceuticals, electric power plants, aerospace, and others.

Portable XRF Analyzer - Alloy Analyzer

APPLICATIONS

Portable XRF Analyzer - Alloy Analyzer

Waste recycling and sorting

Portable XRF Analyzer - Alloy Analyzer

Alloy material identification (PMI) incoming inspection

Portable XRF Analyzer - Alloy Analyzer

Quality control and QA (QC/QA) and effective error prevention (PKKA-YOKE)

FEATURES

Professional brand database

The product's built-in brand database encompasses 380 alloy brands, addressing the challenge of converting various country-specific brands in specialized industry applications. Additionally, users have the flexibility to expand the alloy brand library, enabling simultaneous analysis of over 600 alloy types and more than 10,000 alloy materials.

Extremely low detection limit

The new net strength fitting method, powered by the super-FP algorithm, allows users to accurately analyze metal material and element content without needing to switch modes.

Nondestructive testing (NDT)

The entire testing process poses no risk of damage to the product, and measurements can be conducted under various extreme environmental conditions, including high and low temperatures, dust, darkness, and humidity.

Personalized

The professional management analysis software features security password settings and allows for the generation of customized, personalized analysis reports with the company's logo included.

More Handheld

Handheld XRF Analyzer - Alloy Analyzer with its one-button operation, the instrument offers enhanced convenience. It's also smaller and lighter, making it easy for users to carry. Plus, remote control of the instrument can be easily achieved.

TECHNICAL SPECIFICATIONS

Weight	1.5KG
Size	254×79×280mm□ L×W×H□
Detection range	Mg—U
Excitation source	50kV/200μA upper limit, tube pressure tube flow can be adjusted freely, W/Ag/Rh target (optional)
Detector	Si-PIN detector/SDD detector
Display system	4.3 "industrial grade resistance touch screen Automatically adjust display brightness according to external environment brightness
Data processing	Built-in 32GB storage USB, can connect the device to the Internet, remote setting and maintenance of the instrument
Heat dissipation	T-slot radiator
Security	Built-in DoubleBeam™ technology automatically senses samples ahead for enhanced radiation safety and protection Waterproof, dustproof and shockproof carrying case Special safety rope

Power system	Intelligent battery with MSBUS, real-time monitoring battery, spare battery can directly check the remaining capacity of the battery, the battery complies with the air dangerous goods transport regulations A single battery can work for about 8 hours
--------------	--



TORONTECH

Torontech Inc.

251 Consumers Road, Suite 1200
Toronto, Ontario, M2J 4R3, Canada 🇨🇦

Phone: +1 416 368 2721 | Fax: +1 416 981 7652
Email: info@torontech.com

Torontech, LLC

601 Brickell Key Drive, Suite 700
Miami, FL 33131, USA 🇺🇸

Toll-Free: 1-866-383-7919
Email: sales@torontech.com

Torontech ME FZE

Meydan Grandstand, 6th Floor,
Meydan Road, Nad Al Sheba,
Dubai-261440, UAE 🇦🇪

Phone: +971 488 19252
Email: me@torontech.com



USA | Canada | EU | UAE | GCC | KSA | India | Africa | Latin America | Asia

